

INSTRUCTION MANUAL

AUTO CHARGE 11 AUTOMATIC BATTERY CHARGER

U.L. Configuration



MODEL #091-11-XX

NOTE :

This charger is designed for vehicles with dual batteries and negative ground.

CAUTION

This unit should not be exposed to water spray or rain

3 YEAR WARRANTY

170 Cherry Avenue
West Sayville
New York 11796

**KE KUSSMAUL™
ELECTRONICS**
ENERGIZED AND READY, WHEN SECONDS COUNT
www.kussmaul.com

Phone: 800-346-0857
Fax: 631-567-5826
E-Mail: sales@kussmaul.com

IMPORTANT SAFETY INSTRUCTIONS

1. **SAVE THESE INSTRUCTION** – This manual contains important safety and operating instructions for battery charger Model 091-11-xx
2. Do not expose charger to rain or snow.
3. Use of an attachment not recommended or sold by the battery charger manufacturer may result in a risk of fire, electric shock, or injury to persons.
4. To reduce risk of damage to electric plug and cord, pull by plug rather than cord when disconnecting charger.
5. An extension cord should not be used unless absolutely necessary. Use of improper extension cord could result in a risk of fire and electric shock. If extension cord must be used, make sure:
 - a) That pins on plug of extension cord are the same number, size, and shape as those of plug on charger.
 - b) That extension cord is properly wired and in good electrical condition; and
 - c) That wire size is large enough for ac ampere rating of charger as specified in Table 50.1 of UL 1236, 3/27/02
6. Do not operate charger with damaged cord or plug – replace the cord or plug immediately.
7. Do not operate charger if it has received a sharp blow, been dropped, or otherwise damaged in any way; take it to a qualified serviceman.
8. Do not disassemble charger; take it to a qualified serviceman when service or repair is required. Incorrect reassembly may result in a risk of electric shock or fire.
9. To reduce risk of electric shock, unplug charger from outlet before attempting any maintenance or cleaning.
10. **Warning – RISK OF EXPLOSIVE GASES**
 - a) **WORKING IN VICINITY OF A LEAD-ACID BATTERY IS DANGEROUS. BATTERIES GENERATE EXPLOSIVE GASES DURING NORMAL BATTERY OPERATION. FOR THIS REASON, IT IS OF UTMOST IMPORTANCE THAT EACH TIME BEFORE USING THE CHARGER, YOU READ THIS MANUAL AND FOLLOW THE INSTRUCTIONS EXACTLY.**
 - b) To reduce risk of battery explosion, follow these instructions and those published by battery manufacturer and manufacturer of any equipment you intend to use in vicinity of battery. Review cautionary marking on these products and on engine.

IMPORTANT SAFETY INSTRUCTIONS (Cont.)

11. PERSONAL PRECAUTIONS

- a) Someone should be within range of your voice or close enough to come to your aid when you work near a lead-acid battery.
- b) Have plenty of fresh water and soap nearby in case battery acid contacts skin, clothing, or eyes.
- c) Wear complete eye protection and clothing protection. Avoid touching eyes while working near battery.
- d) If battery acid contacts skin or clothing, wash immediately with soap and water. If acid enters eye, immediately flood eye with running cold water for at least 10 minutes and get medical attention immediately.
- e) NEVER smoke or allow a spark or flame in vicinity of battery or engine.
- f) Be extra cautious to reduce risk of dropping a metal tool onto battery. It might spark or short-circuit battery or other electrical part that may cause explosion.
- g) Remove personal metal items such as rings, bracelets, necklaces, and watches when working with a lead-acid battery. A lead-acid battery can produce a short-circuit current high enough to weld a ring or the like to metal, causing a severe burn.
- h) Use charger for charging a LEAD-ACID battery only. It is not intended to supply power to a low voltage electrical system other than in a starter-motor application. Do not use battery charger for charging dry-cell batteries that are commonly used with home appliances. These batteries may burst and cause injury to persons and damage to property.
- i) NEVER charge a frozen battery.

12. PREPARING TO CHARGE

- a) If necessary to remove battery from vehicle to charge, always remove grounded terminal from battery first. Make sure all accessories in the vehicle are off, so as not to cause an arc.
- b) Be sure area around battery is well ventilated while battery is being charged. Gas can be forcefully blown away by using a piece of cardboard or other nonmetallic material as a fan.
- c) Clean battery terminals. Be careful to keep corrosion from coming in contact with eyes.

IMPORTANT SAFETY INSTRUCTIONS (Cont.)

12. PREPARING TO CHARGE (Continued):

- d) Add distilled water in each cell until battery acid reaches level specified by battery manufacturer. This helps purge excessive gas from cell. Do not overfill. For a battery without cell caps, carefully follow manufacturer's re-charging instructions.
- e) Study all battery manufacturer's specific precautions such as removing or not removing cell caps while charging and recommended rates of charge.
- f) Determine voltage of battery by referring to vehicle owner's manual and make sure that it matches the output rating of the charger.

13. CHARGER LOCATION

- a) Locate charger as far away from battery as dc cables permit.
- b) Never place charger directly above battery being charged; gases from battery will corrode and damage charger.
- c) Never allow battery acid to drip on charger when reading gravity or filling battery.
- d) Do not operate charger in a closed-in area or restrict ventilation in any way.
- e) Do not set a battery on top of charger.

14. DC CONNECTION PRECAUTIONS

- a) Connect and disconnect dc output wires only after interrupting power and removing ac cord from electric outlet. Never allow wires to touch each other.
- b) Attach wires to battery and chassis as indicated in 15(e), 15(f), 16(b), and 16(d).

15. FOLLOW THESE STEPS WHEN BATTERY IS INSTALLED IN VEHICLE. A SPARK NEAR BATTERY MAY CAUSE BATTERY EXPLOSION. TO REDUCE RISK OF A SPARK NEAR BATTERY:

- a) Position ac and dc cords to reduce risk of damage by hood, door, or moving engine part.
- b) Stay clear of fan blades, belts, pulleys, and other parts that can cause injury to persons.
- c) Check polarity of battery posts. POSITIVE (POS, P, +) battery post usually has larger diameter than NEGATIVE (NEG, N, -) post.
- d) Determine which post of battery is grounded (connected) to the chassis. If negative post is grounded to chassis (as in most vehicles), see (e). If positive post is grounded to the chassis, STOP and call factory.

IMPORTANT SAFETY INSTRUCTIONS (Cont.)

15. FOLLOW THESE STEPS WHEN BATTERY IS INSTALLED IN VEHICLE. A SPARK NEAR BATTERY MAY CAUSE BATTERY EXPLOSION. TO REDUCE RISK OF A SPARK NEAR BATTERY (Continued):
- e) For negative-grounded vehicle, connect POSITIVE (RED) wire from battery charger to POSITIVE (POS, P, +) ungrounded post of battery. Connect NEGATIVE (BLACK) wire to vehicle chassis or engine block away from battery. Do not connect wire to carburetor, fuel lines, or sheet-metal body parts. Connect to a heavy gage metal part of the frame or engine block.
 - f) When disconnecting charger, turn any switches to off, disconnect AC cord, remove wire from vehicle chassis, and then remove wire from battery terminal.
 - g) See operating instructions for length of charge information.
16. FOLLOW THESE STEPS WHEN BATTERY IS OUTSIDE VEHICLE. A SPARK NEAR THE BATTERY MAY CAUSE BATTERY EXPLOSION. TO REDUCE RISK OF A SPARK NEAR BATTERY:
- a) Check polarity of battery posts. POSITIVE (POS, P, +) battery post usually has a larger diameter than NEGATIVE (NEG, N, -) post.
 - b) Attach at least a 24-inch-long 6-gauge (AWG) insulated battery cable to NEGATIVE (NEG, N, -) battery post.
 - c) Connect POSITIVE (RED) charger wire to POSITIVE (POS, P, +) post of battery.
 - d) Position yourself and free end of cable as far away from battery as possible – then connect NEGATIVE (BLACK) charger wire to free end of cable.
 - e) Do not face battery when making final connection.
 - f) When disconnecting charger, always do so in reverse sequence of connecting procedure and break first connection while as far away from battery as practical.
 - g) A marine (boat) battery must be removed and charged on shore. To charge it on board requires equipment specially designed for marine use.

IMPORTANT SAFETY INSTRUCTIONS (Cont.)

17. The instructions for a battery charger shall include 16. (a) – (g) as applicable to the particular charger.
 - a) For all grounded cord-connected battery chargers:
GROUNDING AND AC POWER CORD CONNECTION INSTRUCTIONS -
Charger should be grounded to reduce risk of electric shock.
 - b) For grounded, cord-connected battery chargers with an input rating less than 15 amperes and intended for use on a nominal 120-volt circuit:

INTRODUCTION

The Auto Charge 11 Battery Charger is a compact completely automatic charger designed for installation on vehicles with two batteries. Two individual chargers are provided to charge the two batteries. Voltage is sensed separately for each battery so that each battery is charged according to its requirements. The total output to the two batteries is 10 amperes. An ammeter provides continuous indication of the charger output.


Construction of the Auto Charge 11 is extremely rugged to withstand the shock and vibration normally encountered by vehicle mounted equipment. The unit operates completely automatically and stops charging the batteries when they are fully charged. There is no trickle charge and therefore no danger of overcharging and water boil-off. Any parasitic loads on the battery such as radio, lights, etc., are automatically supplied with current by the charger.

INSTALLATION

The Auto Charge 11 Automatic Battery Charger should be installed in an area with adequate ventilation.

1. Mount the charger using the four holes provided for this.
2. Connect the wiring from the batteries to the Output Terminal Strip.
3. Connect the wiring to the batteries. Ring lugs that have been securely crimped, or soldered, should be used.
4. Double check all wiring before proceeding.
5. Wire the A.C. power to power input terminal strip.
6. Pilot light will light to show that the charger has power.

INSTALLATION WIRING DIAGRAM




IMPORTANT: Charger output wire size is 14 awg. Wire size is for a maximum length of 20 feet. If wiring is to be longer, larger wiring is required. Additional information is available on request.

SPECIFICATION & OUTLINE

SPECIFICATIONS:

- Input:** see chart
- Output:** see chart
- Output Current:** see chart
- Charge Indicator:** 0-15 amps 5%
- Weight:** 12 lbs

Model #	Output Current	Output Voltage	Input Voltage	Input Current	Input Fuse
091-11-6	10 Amps	6	120, 50/60 Hz	2.5 Amps	3 Amp
091-11-12	10 Amps	12	120, 50/60 Hz	2.5 Amps	3 Amp
091-11-24	5 Amps	24	120, 50/60 Hz	2.5 Amps	3 Amp
091-11-6-230	10 Amps	6	230, 50/60 Hz	1.3 Amps	1.6 Amp
091-11-12-230	10 Amps	12	230, 50/60 Hz	1.3 Amps	1.6 Amp
091-11-24-230	5 Amps	24	230, 50/60 Hz	1.3 Amps	1.6 Amp



INSTALLATION RECORD & WARRANTY

Date Installed _____

Installed By _____

Vehicle Identification _____

Vehicle Owner _____

WARRANTY

All products of Kussmal Electronics Company Inc. are warranted to be free of defects of material or workmanship. Liability is limited to repairing or replacing at our factory, without charge, any material or defects which become apparent in normal use within 3 years from the date the equipment was shipped. Equipment is to be returned, shipping charges prepaid and will be returned, after repair, shipping charges paid.

Kussmal Electronics Company, Inc. shall have no liability for damages of any kind to associated equipment arising from the installation and /or use of the Kussmal Electronics Company, Inc. products. The purchaser, by the acceptance of the equipment, assumes all liability for any damages which may result from its installation, use or misuse, by the purchaser, his or its employees or others.