

INSTRUCTION MANUAL

GENERATOR METER

VAAFH AC/DC

MODEL: 091-247

3 YEAR WARRANTY



INTRODUCTION

The VAAFH AC/DC is an ideal monitor system for 240/120 generators and grid power sources and provides monitor of load balancing on the 120 VAC legs. Additionally, the AC/DC model now provides DC volts and amps monitoring. This meter meets NFPA requirements 1901 22.4.6.3 for monitoring of permanently mounted generators on fire apparatus. It provides accurate digital metering for AC Volts, Amps, Frequency and logs generator hours. Low/High Voltage, Amperage and Frequency alarms are easily set. When activated, the built-in 85 dB alarm will sound and the affected display reading will change RED for the out-of-limit condition.

The meter is waterproof and rugged with a large color LCD display screen read-out divided into 6 display sections allowing the operator quick, and accurate assessment on the state of the generator output and applied loads.

AC volts are displayed from 90 to 300 VAC and DC volts to 33 VDC, 300 amps max. Two Amperage readouts for both 120V legs of the 240 circuit are displayed from 0 to 150 amps, and Frequency is also displayed. Generator hours are logged and easily viewed via menu selection.

The meter is powered from 12-24VDC. Four levels of backlighting can be selected and the display can be remotely turned ON/OFF. All set-up, calibration and alarm values are saved to non-volatile memory. The system is complete with DC amp shunt, voltage and current transformers, and is factory calibrated to read within 1%. The large LCD display draws only 0.08 amps with full brightness and only 0.02 in sleep mode.


INSTALLATION


Before starting the installation, please read this entire section first

The meter is designed for panel mount in a 2-1/8 hole. Locate a suitable position for the meter, (refer to applicable NFPA regulations) cut mounting hole 2-1/8" (55mm) where you desire to mount the instrument (Figure 1) and secure in position, the gasket provided ensures a waterproof seal against the mounting surface. (Caution it's important that the spacing nuts (2) contact the underside of the mounting bracket. Do not over tighten the mounting nuts). Finger tighten the screws that mount the instrument bracket. It is not necessary or recommended to use tools.

MOUNTING (Figure 1)

Finger Tighten Meter Hardware Only - Do Not Use Tools





170 Cherry Avenue
West Sayville, NY 11796
www.kussmaul.com



Ph: 800-346-0857
Fax: 631-567-5826
sales@kussmaul.com

WIRING AND POWER UP

The following wiring components are provided with the meter:

- 1 ea. Interface Box containing AC voltage transformer and board
- 2 ea. AC current transformers
- 1 ea. DC current shunt
- 2 ea. Tie Wraps

1) Power Wiring (for operating the meter)

The VAAFH is powered from a source of 9.5 to 33.0 VDC. Attach power wiring per diagram, see FIG. 2 & 3. Fuse at source


2) Monitor Wiring

The meter receives voltage and amperage signals from the provided wiring interface box and current transformers. CAUTION: DO NOT APPLY RAW AC VOLTAGE OR CURRENT DIRECTLY TO THE METER, THIS WILL DESTROY THE METER. Attach the signal data wiring to the meter as shown in FIG. 2

3) AC Current Transformer Wiring

Two C.T.'s are provided, each with 40" length two conductor (26 AWG) cable. Wire colors are black and yellow. The yellow and black wires can be connected to the Interface box PCB in either direction, there is no polarity for C.T. connection. Please disregard arrow on top of C.T., there is no current direction for the VAAFH installation. For new installations, we recommend passing the Line side cable of the current carrying source through the center opening in the C.T. (Dia.: .630"). For pre-wired installations, the C.T. donut hole can be opened to allow the C.T. to clamp over the cable. To open C.T. use a small slotted screwdriver; pry up both ends, lift up the non-secured end, release top from plastic latches, clamp over cable and push the two C.T. halves back together and snap the plastic latches shut

Current Transformer: Closed and Open



The VAAFH is designed to operate with the provided interface box. Locate the interface close enough for the VAAFH cable to reach (2' to 2.5'). The box also needs to be located a maximum of 3' from L1 & L2 main feeds for the current transformer leads to reach the Interface box.

4) DC Current Shunt Wiring

A DC current shunt is provided with 16" length three conductor (20 AWG) cable. Wire colors used are black and red. One end will have factory terminated QD's which can be connected to the Interface box, see wiring diagram. The opposite end must be terminated with ring-lugs, provided. Please refer to the wiring diagram for wire color termination and chassis ground

reference. If the DC shunt wiring does not match the wiring diagram the display DC Amps will show a positive sign instead of a negative. The wiring is configured to display a negative sign when the battery is supply power to a load (battery is power source and being drained).

5) Alarm Wiring (Optional)

This terminal produces a +5 VDC signal (100mA max.) with reference to DC when an alarm condition is detected. Maintenance alarm does not affect +5 VDC alarm output. This +5 VDC signal is compatible with Newmar model DIR

(optional), solid state relay which can carry an AC or DC circuit up to 10 amps.

6) Powering Up

Once the meter wiring/installation is complete, double check DC power polarity and then connect 12, 24, or 32 VDC power to meter. It is normal for meter to take 20-30 seconds to start up before the display readings settle. Note: Display refreshes readings every 2 seconds.

MENU NAVIGATION AND CALIBRATION

A) Main Page

When the instrument is powered up it displays the "Main" page. The "Main" page displays: AC Volts, Frequency (HERTZ), AC AMPS #1, and AC AMPS #2. Values are displayed in GREEN if within acceptable alarm set limits or RED if out of limits condition exists.

| DC Volts | DC Amps |
|------------|--------------|
| 13.25 | 300 |
| AC Volts | AC Frequency |
| 120 | 60 |
| AC Amps #1 | AC Amps #2 |
| 40 | 41 |

120V Screen

| DC Volts | DC Amps |
|------------|--------------|
| 13.25 | 300 |
| AC Volts | AC Frequency |
| 240 | 60 |
| AC Amps #1 | AC Amps #2 |
| 0 | 0 |

240V Screen

From MAIN PAGE display:

- Pressing the ▲ key for ½ second (longer than a quick press but shorter than 2 seconds) will cause a white ALARM bell symbol to be displayed and enable the alarms.
- Pressing the ▼ key for ½ second (longer than a quick press but shorter than 2 seconds) will disable the alarms and remove the white alarm bell symbol.

| DC Volts | DC Amps |
|------------|--------------|
| 13.25 | 300 |
| AC Volts | AC Frequency |
| 240 | 60 |
| AC Amps #1 | AC Amps #2 |
| 0 | 0 |

- Pressing the + key for ½ second (longer than a quick press

but shorter than 2 seconds) will increment the backlight level through four different intensities.

B) Generator Hours Page

While in the Main page, a quick press of both ▲ and ★ keys at the same time will bring up the Generator Hours page which includes: Total Generator Hours and Hours till Maintenance Required. This page will revert back to Main page after 10 seconds from the last key press. No access code required to view the Hours page. This page is for viewing of generator and service hours. There are no adjustments available on this page. The Main page is displayed ten seconds from entering the Generator/Maintenance screen or by quick pressing both the ▼ and ★ keys at the same time.

| |
|---------------------------------|
| Total Generator Hours |
| 00000.7 |
| Hours Till Maintenance Required |
| 0199 |

C) Secured Access Pages

While in the Main page or Generator Hours page, a Quick press of the ★ key brings up the Security Access page and a default number 5000 is displayed in the ACCESS CODE box.

| | |
|----------------------|--|
| Security Access Code | |
| Enter Access Code | Change Value 5000 Access Code |
| Down | Accept Up Quit |

Use the ▲ and ▼ keys to scroll to the correct access code and press “ACCEPT” to enter that number (default ACCESS CODE is 1234). The longer you hold down the ▲ or ▼ key, the faster the scrolling of numbers. False entry results in Main Page being displayed. Entry of correct access code unlocks the instrument and brings up the following menu:

| | |
|--------------|----------------|
| AC Alarms | |
| DC Alarms | |
| Calibrate AC | |
| Calibrate DC | |
| Setup | |
| Details | |
| About | |
| Down | Accept Up Quit |

After security access has been granted and you return to the Main page, you have 60 seconds to re-enter the secured pages by quickly pressing the ★ key or you will have to re-enter the security code. You may toggle between the Main page and secured pages without reentering the security code, but will need to re-enter it after 60 seconds from the last key press.

For each menu or sub-menu item the following is true:
Pressing the ▼ or ▲ keys moves highlighted selection down

or up. Pressing the QUIT (★) key returns you to the Main Page. Pressing the ACCEPT key selects the highlighted menu item. Pressing no key for 60 seconds returns you to the Main Page and locks the security access.

D) Alarms

AC

Selecting the AC ALARMS menu brings up the following sub-menu:

AC VOLTS HI (Adjustable from 90 to 300)
AC VOLTS LO (Adjustable from 90 to 300)
FREQUENCY HIGH (Adjustable from 30 to 100)
FREQUENCY LO (Adjustable from 30 to 100)
AC AMPS #1 HI (Adjustable from 0 to 150)
AC AMPS #2 HI (Adjustable from 0 to 150)
MAINTENANCE (Adjustable from 0 to 5000)
← BACK (Returns to previous page)

Use the UP or DOWN button to move to the appropriate item then press the + (ACCEPT) key. Use the ▲ or ▼ keys to increase or decrease the number to the desired value then press the + (ACCEPT) key to set the value and return to the ALARMS menu or the ★ (QUIT) key to set the value and return to the Main page.

| | |
|--------------|----------------|
| AC Alarms | |
| DC Alarms | AC Volts HI |
| Calibrate AC | AC Volts LO |
| Calibrate DC | Frequency HI |
| Setup | Frequency LO |
| Details | AC Amps #1 HI |
| About | AC Amps #2 HI |
| | Maintenance |
| | ← Back |
| Down | Accept Up Quit |

DC

Selecting the DC ALARMS menu brings up the following sub-menu:

DC VOLTS HI (Adjustable from 9.5 to 30)
DC VOLTS LO (Adjustable from 9.5 to 30)
DC AMPS HIGH (Adjustable from 0 to 300)
← BACK (Returns to previous page)


Use the UP or DOWN button to move to the appropriate item then press the + (ACCEPT) key. Use the ▲ or ▼ keys to increase or decrease the number to the desired value then press the + (ACCEPT) key to set the value and return to the ALARMS menu or the ★ (QUIT) key to set the value and return to the Main page.

| | |
|--------------|----------------|
| AC Alarms | |
| DC Alarms | DC Volts HI |
| Calibrate AC | DC Volts LO |
| Calibrate DC | DC Amps HIGH |
| Setup | ← Back |
| Details | |
| About | |
| Down | Accept Up Quit |

E) Calibration AC

Selecting the CALIBRATE AC menu brings up the following sub-menu:

AC VOLTS
 FREQUENCY
 AC AMPS #1
 AC AMPS #2
 ZERO AC AMPS #1
 ZERO AC AMPS #2
 ← BACK



To calibrate the VAAFH meter volts, Hz. and Amps, you will need a separate reference test meter, AC RMS voltage and current probe to measure AC RMS current. All reference meters should have an accuracy of 1% or better. Also you will need a stable voltage and load source. Load source can be lamps or heaters. NOTE: These loads may drift a little so always re verify measurements before adjusting calibration value. Calibration should be performed after installation is complete.

Remove the cover from the VAAFH interface box to gain access to its terminal block. This will be needed to measure AC voltage. WARNING: High voltage is present at terminal block.

AC Volts

Apply AC mains and DC power to circuit. Do not apply a load at this time. Measure the AC RMS voltage at TB1 terminals 9 and 10. Go to the sub-menu of the AC VOLTS calibration menu and adjust the value up or down using the up or down buttons so it matches the measured reading then press the ★ (accept) button when done.

Frequency

Frequency does not typically need calibration. If frequency needs calibration a frequency meter will be needed. Measure the frequency at TB1 terminals 9&10. Got to the sub-menu of the calibration frequency menu and adjust the value up or down using the up or down buttons then press the ★ (accept) button when done. WARNING: High voltage is present at terminal block.

Zeroing AC Amps #1 and #2

Apply AC mains and DC power to circuit. Do not apply any load at this time. Go to the sub-menu of the calibrate menu and select either the ZERO AC AMPS #1 or #2. Zeroing amps should be done before calibrating AC Amps.

AC Amps #1 and #2

Apply AC mains and DC power to circuit and apply a load. Measure the AC RMS current through the load wires (#1 or #2). Go to the sub-menu of the AC AMPS (#1 or #2) calibration menu and adjust the value up or down using the up or down buttons so it matches the measured reading then press the ★ (accept) button when done.

ATTENTION: Calibration should only be performed by qualified personnel. Published accuracies are based on proper calibration in conjunction with the 773-5385-0 meter interface. If it is determined that calibration is needed, first ensure all sense transformers are terminated properly to the meter prior to calibrating.

If the Amps show a positive number when zero amps are being passed through the current transformer it is possible to automatically zero the amps #1 or amps #2 from the “Calibrate” page. At low values of CT voltage there is a slight interaction between the Zero Amps and the

Calibrate Amps and it may require you to re-calibrate slightly after you have used the Zero Amps feature.


If the user accidentally zeros the amps #1 or amps #2 while positive amps are actually being passed through the current transformer, the meter will no longer display amps correctly and the amps offset will have to be cleared. This is done by holding the ▼ key for more than 10 seconds while the meter is displaying “NO YES NO NO” on the “Setup”→”Reset Alarm Bell” page. This feature has been hidden to make it difficult to do by accident.

Trying to calibrate the instrument when in simulate mode will be problematic since the simulated inputs are constantly changing.

F) Calibration DC

Selecting the CALIBRATE DC menu brings up the following sub-menu:

DC VOLTS
 DC AMPS
 ZERO DC AMPS
 ← BACK



DC Volts

Apply DC power to circuit. Do not apply a load at this time. Measure the DC voltage at interface terminal block, across (+)DCV and (-) DCV. Go to the sub-menu of the DC VOLTS calibration menu and adjust the value up or down using the up or down buttons so it matches the measured reading then press the ★ (accept) button when done.

Zeroing DC Amps

Apply DC power to circuit. Do not apply any load at this time. Go to the sub-menu of the calibrate menu and select: ZERO DC AMPS. Zeroing DC amps should be done before calibrating DC Amps.

DC Amps

Apply DC power to circuit and apply a load. Measure the DC

current through the DC load shunt. Go to the sub-menu of the DC AMPS calibration menu and adjust the value up or down using the up or down buttons so it matches the measured reading then press the ★ (accept) button when done.

F) Set-Up

Selecting the SETUP menu brings up the following sub-menu:

| |
|---------------------|
| Access Code |
| Zero Generator HRS |
| Maintenance Alarm |
| Current Value |
| Reset Alarm Bell |
| <- Back |
| |
| Down Accept Up Quit |

- ACCESS CODE
 ZERO GENERATOR HOURS
 MAINTENANCE ALARM
 CURRENT ▲ VALUE
 RESET ALARM BELL
 ← BACKACCESS CODE ← Lets the user change the access code
 ZERO GENERATOR HOURS ←Will ZERO the generator hours (after asking if sure)
 MAINTENANCE ALARM ← User can set the Maintenance alarm value
 CURRENT ▲ VALUE ← User can set the current value to count down from (Hours)
 RESET ALARM BELL ← Remove RED alarm bell symbol from Main Page (maintenance alarm) and Resets “CURRENT ▲ VALUE” to “MAINTENANCE ALARM” value

← BACK

A) Access Code Setting

If no key has been pressed for 60 seconds from any of the menus or submenus, the instrument will revert to displaying the Main Page.

The ACCESS CODE is required to access alarm settings, instrument setup and calibration menus. Set the ACCESS CODE to a number from 0000 to 9999 by using the ▲ or ▼ keys then press the + key to accept. The factory default is set to 1234.

If the ACCESS CODE is ever forgotten, the instrument can be reset back to factory default (see “Reset to Default”). Caution: Resetting to factory default will reset all alarm and calibration settings as well.

B) Zero Generator Hours Setting

Select this to set the TOTAL GENERATOR HOURS to zero either for new generator installs or after a generator has been replaced.

C) Maintenance Alarm Setting

This sets the alarm interval for the RED maintenance indicator bell.

Setting the MAINTENANCE ALARM value to zero will disable the maintenance alarm. The RED bell will not be displayed and the current maintenance alarm value will be set to zero.

CURRENT ▲ VALUE

This is the hours remaining before maintenance alarm. Note: This value is set to “maintenance alarm” value when you do reset alarm bell

D) Details Display

Selecting the DETAILS menu brings up an information page that displays:

- SERIAL NUMBER (YYMMDDnnn)
 ACCESS CODE nnnn
 INSTRUMENT ON HOURS
 AC VOLTS HI AND LO ALARM VALUES
 FREQUENCY HI AND LO ALARM VALUES
 AMPS #1 AND #2 HI ALARM VALUE
 DC VOLTS HI AND LOW ALARM VALUES
 DC AMPS HI ALARM
 GENERATOR HOURS
 MAINTENANCE ALARM VALUE
 HOURS TO GO TILL MAINTENANCE IS REQUIRED

| Details | |
|-----------------------------|-------------------|
| SN: 150629011 | Access Code: 1234 |
| Instrument on Hours: .9 | |
| AC Volts Alarm Hi: 150 | LO: 100 |
| Frequency Alarm Hi: 70 | LO: 50 |
| AC Amps HI Alarm #1: 140 | #2: 140 |
| DC Volts Alarm Hi: 33.00 | LO: 9.50 |
| DC Amps HI Alarm: 250 | |
| Generator Hours: .1 | |
| Maintenance Alarm: 200.0 | |
| Hours to Maintenance: 200.0 | |
| Back | Back Back Quit |

E) About

Selecting the ABOUT menu brings up an information page that displays

- Software Version (S/W)
 Hardware Version (H/W)
 NEWMAR web page

| | | | |
|---|------|------|------|
| Kussmaul Electronics AC/DC Monitor S/W= 21 H/W= 50 www.kussmaul.com COPR. 2010, 2015 Cruzpro LTD. | | | |
| Back | Back | Back | Quit |

RESET TO FACTORY DEFAULT

Holding down the ▼, + and ▲ keys on power-up will bring up a menu that allows the user to reset the instrument back to factory defaults. The calibration and alarm values will all be set to nominal and the instrument will have to be recalibrated. The security code will reset to default 1234.

On the CALIBRATE submenu the ▼ and ▲ buttons are used to calibrate the selected value (such as FREQUENCY) and the + key accepts that value. Pressing the ★ key quits the menu system and causes the Main Page to be displayed.

SPECIFICATIONS

Power Supply: 9.50 to 33.00 VDC, @ 100mA

Operating Temperature: 32° to 122° F (0° to 50° C)

Size: 4.3" x 4.3" x 3.5" deep (110 x 110 x 89 mm).

Display Data:

AC Volts: 90-300 VAC

AC Amps: 0-150 amps

Frequency: 30 to 100 Hz.

DC Volts: 9.5-30 VDC

DC Amps: 0-300 amps

Hour Meter: 99,999.9 Hrs.

Resolution: 1 VAC, 1 AC amps, 1hz.

Accuracy: Volts: 1% +/-1 digit

Amps: 2% +/-1 digit

Frequency: .5%

Hours: .5%

Supplied Transducers: Voltage (1 each) AC Current transformers (2 each) and DC Current Shunt (1 each)

Alarms: High/Low Voltage, High & Low Frequency, High Amps